



**INNOV8**  
RACING INC.™

# SIMU-LOCK INSTALLATION INSTRUCTIONS

1. Check wheel for clearance and fitment prior to mounting tire. Make sure correct bolt pattern applies.  
**No credit will be issued on mounted wheels, mounting this wheel means you own it.**
2. Install the valve stem then mount tire from the front side. Use tire mounting lube on the wheel to ensure proper seat for the tire.
3. Place the simulated beadlock ring on the face of the wheel, aligning it with the bolt holes.
4. Before installing the hardware, lubricate the bolts with anti-seize or grease.  
Optional Low strength loctite (purple) can be used.
5. Install the supplied bolt and washer. All bolts should be started by hand to avoid cross threading. Impact wrenches are not recommended for installing hardware due to the possibility of over or under tightening.
6. **Tighten all of the bolts to 4-6 ft/lbs** in a circular pattern. Do not overtighten.
8. Inflate tire to seat inner bead on wheel. Always use safe practices, such as a tire safety cage and clip-on air chuck with extended whip hose and a remote pressure regulator. Never under any circumstances exceed tire or wheels recommended air pressure.  
Over inflation could lead to serious injury or death.
9. Balance the wheel & tire assembly and install per factory specs.

## CLEAN & CARE INSTRUCTIONS

1. Spray off and hand wash with mild soap and water only.
2. Do not use harsh cleaners, wheel, or brake cleaners. Most products on the market are too acidic and can damage finishes.
3. Do not use tire dressings or tire cleaners.
5. Most detail sprays that are used on painted surfaces work well on wheels.
6. We recommend ceramic coatings such as Shine Supply Beadlock & Carpro CQuartz to help protect your wheels.
8. For aggressive offroading we recommend using WD40 prior which helps prevent mud & dirt from sticking to the surfaces.

### WARRANTY

- If your Innov8 Racing Inc. product is defective in material or workmanship and you return it to us within one year from the date of purchase, we will replace it or, at our option, repair it at no charge to you.
- The warranty does not cover any damage caused by accident, misuse, failure to follow installation and operation instructions, misapplication, alteration, or attempted unauthorized repair service by anyone other than Innov8 Racing Inc.
- The warranty only applies to original purchasers of Innov8 Racing merchandise and is non transferrable.

e. [sales@Innov8Racing.com](mailto:sales@Innov8Racing.com)  
w. [Innov8racing.com](http://Innov8racing.com)  
i. [Innov8\\_Racing\\_inc](http://Innov8_Racing_inc)